

700 Series Use and Care Guide



Introducing the 700 Series

Integrated Refrigeration

The Sub-Zero 700 Series brings you true innovation! It is the first *integrated systems approach* to domestic refrigeration, offering you three significant advantages.


- Integrated systems refrigeration gives you the choice of proportion ... of refrigeration to freezer temperatures to meet your needs. Storage below counter height level is a drawer, while storage above the counter is a cabinet. The ergonomic division of space increases your access to storage areas.
- Integrated systems refrigeration gives you the choice of location of refrigeration units throughout your kitchen. This helps you meet your individual needs for the way you use a kitchen.
- Integrated systems refrigeration gives you total aesthetic integration with cabinets you have chosen. Refrigeration units, in essence, are refrigeration cabinets. They literally become a part of the kitchen furniture.

Your Sub-Zero 700 Series unit is protected by a warranty that is second to none. Please read it and keep this book as a reminder of the excellent protection it gives you. See page 22 for the warranty


This use and care book is meant to answer most of the common questions you may have about the general operation of your 700 Series unit. If you have any questions that need further addressing please call 800/200-7820 for your local product distributor or Sub-Zero.

Refrigerator Units

Model 700 TR




Model 700 BR




Freezer Units

Model 700 TF/TFI




Model 700 BF/BFI



Combination Unit

Model 700 TC/TCI



Features of the 700 Series

Sub-Zero's tradition of integrated design and quality continues in the 700 series, with the following standard features.

Seamless Molding

A single piece of molding forms the complete front of each unit's interior, giving a sculptured look that is both utilitarian and elegant.

Electronic Control Panel

A microprocessor controls all electronic functions ... temperature, adaptive defrost, lights, cooling fan, and door/drawer ajar warning. The liquid crystal display (LCD) lets you monitor all temperature zones on the unit, and easily make adjustments.

Halogen Lighting

Flat to the ceiling, this superior lighting provides white, efficient light in cabinet and drawer units.

Dairy Shelf

A positive-sealing dairy compartment, divided by a small internal wall, is standard on tall and combination refrigerator units. This fully adjustable compartment is a convenient place for deli foods and small items that need a fresh environment.

Adjustable Shelves

A single sculptured molding, with tempered glass molded into it, forms each sealed, adjustable shelf. This design feature prevents spills from dripping throughout the unit.

Crisper Compartment

A large, enclosed crisper comes with the refrigerator/freezer combination unit. An interchangeable lift-up cover provides maximum humidity in the base and tall refrigerator units, helping you keep produce at its best quality, longer.

Ice Container

This clear, molded container is easily removable from the lower drawer. It is offered as an option on the base and tall freezers, as well as the combination refrigerator/freezer.

Deli Compartment

This enclosed compartment in refrigerator units is adjustable with the shelves. It gives you a convenient area for deli foods or other small items.

Egg Tray

A portable egg tray offers handy storage and is easily removable.


Using Your Sub-Zero Unit

The Electronic Control Systems

The sophisticated electronic control system provides you with the best control of your refrigerated foods. By maintaining recommended refrigerator and freezer temperatures, you can keep food safe and retain the best quality possible.

A microprocessor accurately controls the temperature of the cooling zones. It samples the temperature every second, and makes adjustments to maintain the temperature you have indicated.

The control panel is located on the top of the tall units, and in the top drawer of the base. All of the essential controls and information are displayed in this easy-to-reach-and-see panel.



Tall unit control panel

LCD Display

This display shows the actual temperature of different zones in your unit. The temperature and name of each corresponding zone appear every five seconds.

Zone Button

By pressing this button, you can see the temperatures set in different zones of your unit. For example, if you press this button and the words "top drawer" are flashing, you will see the temperature of that zone displayed.

Colder Button


This button allows you to decrease the temperature of a selected zone.

Warmer Button

Similar to the colder button, you can raise the temperature in any zone by pressing this button.

Alarm Button

You can turn the alarm on or off with this button, or stop it with this control once the alarm has sounded.



Base unit control panel

How to Adjust Temperatures

If you need to adjust the temperature in any area of the unit, press the *zone button*, until the name of the zone you want to adjust is flashing. If you do not adjust the temperature within five seconds, the control panel will automatically go out of the set mode and continue to monitor the unit.

To decrease the temperature

When the selected zone is displayed, you can decrease the temperature in that zone by one degree each time you press the *colder button*. For example, if you have selected the “cabinet” zone and a temperature of 38°F is displayed, you can decrease the temperature by pressing the colder button two times.

To increase the temperature—

Similar to the *decrease temperature* instructions, you can increase the temperature by one degree each time you press the warmer button for the zone you have selected.

Recommended Temperature Settings

Refrigerator units are factory pre-set to maintain zones 38° Fahrenheit. The temperature range is 34° to 45°F.

Freezer units are factory pre-set to maintain zones at 0° Fahrenheit. The temperature range is +5° to -5°F.

To use the integrated system efficiently, set temperatures to decrease from the top cabinet to the lower drawer. A suggestion that offers great flexibility is...

- cabinet 38°F
- top drawer 36°F
- lower drawer 34°F


How to Operate the Alarm

When your alarm is *on*, the alarm bell will be illuminated on the control panel. To turn the alarm *off*, press the alarm button one more time to make the bell disappear from the display.

Using Your Sub-Zero Unit

Shelves

You can remove or adjust the tempered glass shelves by tilting the shelf *up* at the front, then lifting *up and out of the tracks* on rear wall of the refrigerator or freezer, as shown in the diagram.



Glass shelf removal

To clear the door shelves, lift and tilt the right end of the shelf up, and tilt the left end down. Then lift out the shelf, clearing the unit's door shelves.

⚠ CAUTION


Always exercise care when you handle the glass shelves, to prevent breakage or scratching the interior.

To replace shelves, select the desired shelf height. Then, with the shelf front raised slightly, place shelf in tracks at the rear of the unit. Lower the front of the shelf until it locks into position.

Drawers


To remove a drawer front your unit, pull it open until it stops. Raise the drawer front and pull out, as shown in the diagram.

To replace a drawer, raise the front of it and place onto the tracks. Be sure to engage the front holes of the drawer rail with the small pegs at the end of each rail.



Drawer removal

Where you are removing the top drawer of a base unit, you must disconnect the control cable before removing the drawer. Refer to the diagram.




Control cable disconnection.

Crisper Cover

One crisper cover is standard with each tall and base refrigerator. You can easily remove this cover for cleaning or moving to another drawer by lifting the front edge up and pulling out from the back.


The clear-view window allows easy access and visibility to all vegetables stored in the drawer.



Crisper lid removal

Drawer Divider

The drawer divider is easily removed by pulling forward and sliding the back edge away from the back of the drawer. Reverse the procedure as illustrated in the diagram for installation.




Drawer divider insertion

Door Shelves and Dairy Compartment

The door shelves and dairy compartment are adjustable within the guides of the door liner.

To remove, lift straight up and out from the bottom.

To replace, select a desired position and push down into the guides.



Door shelf removal

Using Your Sub-Zero Unit

Deli Shelf and Drawer

The deli shelf and drawer assembly is one piece and is easily removed for cleaning and repositioning for your use. The small deli drawer is convenient for those small easy-to-loose items as well as to keep deli items fresh.

Remove this assembly in much the same way you remove the standard shelves in your unit. Refer to the instructions and diagram under *Shelves*.

Glass Tray

Tall Units

The glass tray with tall units only is packed on the top shelf of your Sub-Zero. Place this shelf on the bottom portion of the top cabinet area. It is necessary to have this glass installed properly to ensure an even flow of air through the 700 Series unit.

Do not place food or packages close to the edges of the walls.

Icemaker

Freezer Units

The icemaker in your Sub-Zero is fully automatic and has been factory re-tested. To put into operation it requires only a connection to the house water supply. The icemaker shuts off when you remove the ice storage container from the freezer. When you replace the container, the icemaker will resume producing ice.

When you fill the first ice bucket with ice, you should toss this supply out as in any new connection, there may be dirt in the ice.

Sounds

Certain noises may be evident with the normal operation of the unit. Surrounding acoustics like walls, floors and cabinets may affect the sound level of your unit.

General Maintenance

Cleaning


Your 700 Series unit, like all kitchen appliances, is necessary to keep clean to ensure a smoother operating unit and keep food safe. Clean any general spills on the interior with mild, soapy, warm water. Do not use any abrasive cleaners as you may scratch interior surfaces.

Condenser

⚠ WARNING

For maintenance and cleaning, we recommend the circuit breaker or master power switch to the unit be shut off.

Important Note: To ensure efficient performance of your 700 Series unit, your condenser must be cleaned regularly. This should be done every three months under normal use.



Condenser location

To clean this area remove the screws holding the toe kick in place. The toe kick plate will slide forward easily, giving you access to the condenser area. Use a soft bristle brush and vacuum hose to remove the accumulation of dust and lint particles. If you have pets in your home you may want to clean the condenser area more often than once every three months.

Shelves

All refrigerator and freezer compartment glass shelves are dishwasher safe and may be cleaned in this manner. However, you can clean them with a mild solution of soap and lukewarm water. Rinse and dry thoroughly.

⚠ CAUTION

Do not submerge or pour hot water over cold glass shelves. Allow them to come to room temperature before cleaning.

General Maintenance

Lighting Information

You will quickly notice the absence of any light switches on your 700 Series unit. In the upper cabinet portion of a tall unit, the switch is mounted to the interior of the door itself and as it passes a point in closing, it breaks a circuit enabling the light to go out.

Switches in the drawer compartment are mounted on the right side of the drawer area. In some instances the drawer switch may interfere with the safe closing of a drawer. If this occurs, merely move the switch to the raised position and try closing the drawer again. **Do not force** the drawer to close.


Light Bulb Replacement

⚠ CAUTION

For your safety, the circuit breaker to the unit should be shut off or turn off the master power switch before replacing bulbs. Protective gloves should be worn when handling bulbs.

Top Compartment

If you need to replace a 35 watt halogen light in the tall unit's top cabinet, you must open the control panel area.



Light bulb replacement in tall unit's top cabinet.

Do not pull the panel down from the center. Instead, grasp the edges of the control panel and pull down. Two tabs on each corner will release enabling the panel to drop down.

⚠ CAUTION

The halogen lights may be very hot and may burn you. Use a soft cloth or protective gloves and grasp the bulb firmly and pull straight up.

Follow the reverse steps in replacing the bulb and positioning the control panel.


Drawer Compartment

To replace a light bulb in the drawer compartment, you must pull the drawer out to its maximum extension. You may find it easier to remove the entire drawer.

Slide the glass lens to the left, revealing the 20 watt halogen light bulb. Remove the bulb by pulling straight out and complete the reinstallation by following the reverse of these steps.

⚠ CAUTION


To prevent a possible burn, grasp the bulb with a soft cloth or protective gloves.



Light bulb replacement in drawer compartment.

Master Power Switch

All the 700 Series units have a master power switch. The switch, located behind the toe kick plate, will turn off all electrical power to the equipment. This switch can be used for either shutting down the unit for servicing or during extended vacations.




Master power switch.

90 Degree Door Stop

Your tall 700 Series unit is equipped with a built-in 90 degree door stop for the top compartment.

You can easily actuate the stop by using a blade-type screwdriver and advancing the brass fitting in both the top and bottom hinges. You must actuate both



Actuating the 90° degree door stop.

stops at 90 degrees is you want to safely use the door.

You can go to the maximum of 119 degree opening by using the screwdriver and advancing the brass cam to the next stop.

⚠ WARNING

The door swing on the tall 700 Series unit may cause severe finger pinching or damage to the unit itself. Watch that fingers are not placed in the door opening on the hinge side when the door is open.

Also, when the door is open to 119 degrees, the door panel, depending on its thickness, may strike the face frame of the Sub-Zero causing serious damage to the unit.

Vacation Time

For extended vacations your Sub-Zero should be turned off or the circuit breaker can be shut off. Empty all contents in the unit and block the doors open slightly. About one inch space will let fresh air in to keep the interior dry.

During short vacations, you should remove all perishable items and leave the temperature settings at their set point.

If for any reason this unit is put into service on a temporary basis, and later shut off, the doors should be blocked open to allow fresh air to circulate with the compartments. Also, the circuit breaker to the unit should be shut off.

Troubleshooting

If refrigerator/freezer is not operating–

- Is there electrical power to equipment?
- Is home fuse blown or circuit breaker off?
- Is refrigerator/freezer control off?
- Is your condenser clean?
- If still not running, unit may be in defrost; wait 30 minutes to see if unit will restart.

If refrigerator/freezer is warmer than usual–

- Is control set properly?
- Has door been open too long?
- Have you recently added a large quantity of food?

If refrigerator/freezer runs too much–

- Is condenser clean?
- Has door/drawer been open for extended time of large amounts of food added?

If refrigerator/freezer is frosted up–

- Has door been left open?
- Are doors closing and sealing properly?

If condensation forms inside the unit–

- This is normal during high humidity and frequent door openings.

If condensation forms on the outside–

- Be sure door/drawer is closed and gasket is sealing.

If there is odor in the unit–

- Completely clean the product.
- Cover all food tightly.

If light bulb needs replacing–

⚠ WARNING

- Turn off circuit breaker to Sub-Zero, wear gloves to protect against broken glass or burns.

LCD display board warnings–

- If the following numbers of flashing words appear in the LCD display board, you should keep the door/drawer closed as much as possible and call your Sub-Zero service center for assistance.
- 20 displayed and indicator flashing
- 55 displayed and indicator flashing
- Su displayed and top lights off
- -88 displayed, top lights off and buttons do not operate
- buttons do not operate and top lights are off

Keeping Food at its Best

Keeping Food Fresh

Your Sub-Zero unit is the most advanced refrigeration system available to help keep food fresh, and keep it safe to eat.

But the quality and safety of your food depends not only on having the best refrigeration system. It also depends on *you* and how you handle your food.

The information in this section gives you the most current food handling and storage recommendations to help you keep food at its best. If you have specific questions that are not addressed here, contact your University or County Extension Service, or your local utility company.

Most food deteriorates over time. That is inevitable. From the time it is harvested, slaughtered, or manufactured, until it is consumed, food undergoes changes. Microorganisms (bacteria, yeasts and molds) get into food, multiply in number, and cause spoilage. Enzymes that occur naturally in food continue the ripening process, even after the food is harvested. Improper temperatures cause food to deteriorate faster. Changes in humidity cause wilting and shriveling that can lead to spoilage.

But good handling practices can minimize the rate of changes in food...

- Follow the recommended storage times and temperatures on page 17. Your Sub-Zero unit accurately maintains temperatures in different temperature zones, helping to slow the growth of food spoilage microorganisms, and slow the ripening process.
- Use specially designed compartments for dairy foods, deli foods, and fresh produce. These compartments maintain temperature and humidity levels that keep foods fresh.
- Rotate food in refrigeration units, using a “first-in-first-out” system.

When food does spoil, it's usually obvious. It becomes moldy, has an off-odor, looks rotten, slimy, or discolored. But there are times when it may not be so obvious. *As a general rule, if you think a food has been stored too long and may be spoiled, discard it. Don't taste it to check and see if it's ok. While the bacteria that cause this kind of food spoilage will not cause food-borne illness, or food poisoning, it's not a recommended practice.*

Keeping Food at its Best

Keeping Food Safe to Eat

Most foodborne illness is caused by bacteria such as staphylococcus aureus, salmonella, perfringens, e coli, and botulism. These bacteria grow rapidly at temperatures between 40°F and 140°F, a range that's called the Danger Zone. *Food should never be left in the Danger Zone for more than two hours.* When the bacteria have multiplied to the millions in warm temperatures, they cause illness. Some bacteria cause flu-like systems, while others cause serious illness or become fatal. *Young children, the elderly, and people who are already ill are more likely to become sick from food poisoning.*

To reduce your risk for foodborne illness, use the following techniques to keep your food safe to eat.

When You're Shopping

- Place packages of raw meat, seafood or poultry in plastic bags to keep them from dripping on other foods.
- Shop for meat, seafood and poultry *last*. Don't leave these foods in a hot car when you have finished shopping. Take along a cooler in hot weather or when you have to travel long distances.
- Check "use-by" or "sell-by" dates on foods to make sure they are fresh.
- Use extra care when buying deli food. Buy only the amount you will use in 1-2 days. Discard any hot or cold deli food that may have been at room temperatures for more than two hours.

When You Store Food

Monitor temperatures of refrigeration zones on the electronic control panel of your Sub-Zero unit. Refrigerator temperature should be kept at 40°F or below, and freezer temperature should be kept at 0°F.

Follow the recommended refrigerator and freezer storage times and temperatures on page 21.

Store raw meat, poultry and seafood separate from other foods. Keep juices from these packages from dripping on other food.

Never taste food that looks or smells strange to see if you can still use it. *Discard it.*

Keep eggs in their carton in the refrigerator. Discard any cracked or broken eggs.

For refrigerator storage, leave raw meat, poultry and seafood in its original wrapper unless it is torn. *Repeated handling can introduce bacteria to these foods.* For freezer storage, use freezer wrap, freezer-quality plastic bags, or aluminum foil over the commercial wrap if foods will be stored in the freezer for more than a couple of months. This minimizes dehydration and quality loss.

When You Store Food

Food stored in refrigerator units should be wrapped in foil or plastic wrap, or placed in plastic bags or airtight containers to keep it from drying out. *Date all packages.*

Food stored in freezer units should be wrapped in freezer wrap, or placed in freezer-quality plastic bags or freezer containers. (Single layers of aluminum foil may not be adequate—this wrap can develop holes and cause freezer burn.) *Date all packages.*

When You Prepare Food

Clean everything that comes in contact with food.

- Wash your hands for 20 seconds before and after handling food.

- Sanitize counters, equipment and utensils after handling raw meat, seafood or poultry (rinse with a dilute chlorine bleach solution—1 teaspoon/quart of water).

Use clean kitchen towels, sponges and cloths. Replace sponges every few weeks.

Use disposable plastic gloves if you have an infected cut or burn on your hands.

Thaw food in the refrigerator or microwave, not on the counter. When you thaw food in a microwave oven, you should cook it immediately.

Marinate food only in the refrigerator.

Rinse poultry and seafood in cold water before cooking.

Avoid *cross contamination* in preparing food. Keep raw meat, poultry, and seafood and their juices away from other food. For example, don't use the same surface and utensils for preparing raw meat poultry and seafood as you would for preparing salad ingredients.

Thoroughly clean your cutting boards (plastic and wooden). Wash with hot water and soap, and rinse with a dilute chlorine bleach solution (1 teaspoon/quart of water).

Keeping Food at its Best

When You Cook Food

Don't taste raw or partially cooked meat, poultry, eggs, or fish.

Cook meat to an internal temperature of 165°F or above, poultry to 180°F or higher. For cuts more than two inches thick, use a meat thermometer to check the temperature. For thinner cuts, clear juices (not pink) are signs of doneness.

If you are cooking frozen meat or poultry that has not been defrosted, increase the cooking time to 1 1/2 times the time required for thawed items.

Roast meats or poultry in oven temperatures of 325°F or above.

Cook eggs until the yolk and white are firm, not runny. Don't use recipes in which eggs remain raw or partially cooked.

If your microwave has a temperature probe, use it. Check temperatures of meat and poultry in at least three spots. Rotate foods during microwaving.

When You Have Leftovers

Refrigerate or freeze cooked leftovers in small, covered containers within 2 hours after soaking. Make sure there is adequate air space around containers, so food can cool down more quickly.

Remove stuffing from meat or poultry; store it separately.

Date packages of leftovers and use within a safe period of time.

Cover and reheat leftovers thoroughly before serving. Bring sauces, soups and gravy to a boil. Heat other foods to 165°F.

If you think a food may have spoiled, discard it. *When in doubt, throw it out.*

Suggested Food Storage

A note about the following chart: The time limits for refrigeration will help keep food from spoiling or becoming dangerous to eat. The time limits for frozen foods are to maintain flavor and texture. If food is kept longer than the recommended time in the freezer, it will still be safe to eat, but the quality won't be as good.

Keeping Food at its Best

Food	Form	Refrigerator at 32-40°F	Freezer at 0°	Comments
Eggs	fresh, in shell hardcooked liquid pasteurized or egg substitutes opened unopened	3 weeks 1 week 3 days 10 days	don't freeze don't freeze well don't freeze 1 year	
Deli Foods	thinly sliced lunch meats store prepared or homemade egg, chicken, tuna, ham, macaroni salads pre-stuffed chops, chicken breasts store-prepared convenience meals	1-2 days 3-5 days 1 day 1-2 days	don't freeze well	check use-by or sell by dates If you are going to freeze any of these foods, freeze immediately...not after they have been held in the refrigerator.
Soups and Stews	vegetable or meat added	3-4 days	2-3 months	
Hamburger, Ground and Stew Meats	hamburger and stew meats ground turkey, veal pork, lamb and mixtures	1-2 days 1-2 days	3-4 months 3-4 months	
Packaged Hotdogs and Lunch Meats	hotdogs, opened package unopened package lunch meats, opened package unopened package	1 week 2 weeks 3-5 days 2 weeks	in freezer wrap, 1- 2 months	check "sell-by" dates, do not use more than one week after this date.
Bacon and Sausage	bacon sausage (pork, beef, turkey), raw smoked breakfast links, patties hard sausage-pepperoni, jerky sticks	7 days 1-2 days 7 days 2-3 weeks	1 month 1-2 months 1-2 months 1-2 months	
Ham and Corned Beef	corned beef ham, whole ham, half ham, slices	in pouch with pickling juices 5-7 days 7 days 3-5 days 3-4 days	drained, wrapped 1-2 months 1-2 months 1-2 months	
Fresh Meat	beef steaks, roasts lamb chops, roasts pork and veal chops, roasts variety meats (tongue, liver, etc.)	3-5 days 3-5 days 3-5 days 1-2 days	6-12 months 6-9 months 4-6 months 3-4 months	
Meat Leftovers	cooked meat and meat dishes gravy and meat broth	3-4 days 1-2 days	2-3 months 2-3 months	
Fresh Poultry	chicken or turkey, whole chicken or turkey, pieces giblets	1-2 days 1-2 days 1-2 days	1 year 9 months 3-4 months	
Cooked Poultry	fried chicken cooked poultry dishes pieces, plain pieces covered with broth or gravy chicken nuggets, patties	3-4 days 3-4 days 3-4 days 1-2 days 1-2 days	4 months 4-6 months 4 months 6 months 1-3 months	

Service Information

Service

If you need service...

Take the necessary steps to pre-serve food in your unit.

Door/drawers should be left closed as much as possible when unit is back in service. Please have model and serial number available (*look for them on the left-hand side of the top drawer compartment*). Call your nearest Sub-Zero Factory Authorized Service Center in your area, your dealer or Sub-Zero Freezer Company, P.O. Box 44130, Madison, WI 53744-4130. Telephone 800/222-7820.

For installation questions or general product operating information call 800-200-7820 for your local product distributor or Sub-Zero.

"Sub-Zero Protection Plan"

Full 5 Year Warranty and Limited 6th Through 12th Year Warranty on the Sealed System

Full 2 Year Warranty on Total Product

Full Five Year Warranty

For five years from the date of original installation, your Sub-Zero warranty covers all parts and labor to repair or replace any components that prove to be defective in materials or workmanship in the sealed system. The sealed system consists of the compressor, condenser, evaporator, drier and all connecting tubing.

Full Two Year Warranty

For two years from the date of original installation, your Sub-Zero warranty covers all parts and labor to repair or replace any part of the product which proves to be defective in materials or workmanship.

Limited 6th Through 12th Year Warranty

From the 6th through the 12th year from the date of original installation, your Sub-Zero warranty covers all parts that prove to be defective in materials or workmanship in the sealed system (parts only). The sealed system consists of the compressor, condenser, evaporator, drier and all connecting tubing.

Terms Applicable To Each Warranty

All service provided by Sub-Zero under the above warranty must be performed by authorized Sub-Zero service representatives, unless otherwise specified by Sub-Zero. Service will be provided in the home during the normal business hours. This warranty applies only to products installed for normal residential use. Details regarding a non-residential warranty are available upon request.

The warranty applies only to products installed in any one of the fifty states of the United States, the District of Columbia or the ten provinces of Canada. This warranty does not cover any parts or labor to correct any defect caused by negligence, accident or improper use, maintenance, installation, service or repair, including but not limited to improper removal and reinstallation (whether in the unit or at a remote location) of the condensing unit.

The remedies described above for each warranty are the only ones which Sub-Zero will provide, either under these warranties or under any warranty arising by operation of law. Sub-Zero will not be responsible for any consequential or incidental damages arising from the breach of these warranties or any other warranties, whether express, implied or statutory.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.

To receive parts and/or service and the name of the Sub-Zero authorized service representative nearest you, contact your Sub-Zero dealer or distributor or contact Sub-Zero Freezer Company, Service Department, P.O. Box 44130, Madison, Wisconsin, 53744-4130 or call (800)222-7820.



Sub-Zero Freezer Company, Inc. Post Office Box 44130 Madison, Wisconsin 53744-4130 800-200-7820 or 608-271-2233